

# SmartMount™

## Universal Tilt Wall Mount

For 13" to 42" Flat Panel Screens

**NEW!**

Patent Pending



The SmartMount Universal Tilt Wall Mount supports virtually any 13" to 42" flat panel screen. The tilting wall plate keeps the screen close to the wall for a very discreet installation that is perfect for digital signage, POS stations, or office applications. Featuring one-touch tilt, the SmartMount allows the screen to be tilted +15/-5 degrees without the use of tools. For a quick and easy installation it may be mounted to a single wood stud or concrete. Metal stud mounting is possible with accessory metal stud fasteners. Compatible with VESA 75mm, 100mm, 200mm and 200mm x 200mm mounting hole patterns.

- Fits 13" to 42" flat panel screens
- One-touch tilt for effortless positioning and adjustment of the screen
- Models available with integrated security features provide effective theft deterrence
- Standard models also available

**ST635, ST635-S  
ST635P, ST635P-S**

# SmartMount™

## Universal Tilt Wall Mount

### For 13" to 42" Flat Panel Screens

#### Model Numbers

ST635, ST635-S (Security models)  
ST635P, ST635P-S (Standard models)

#### Product Specifications

- Comes in silver or black
- Universal mount fits virtually any 13" to 42" flat panel screen
- Screen adapter brackets included compatible with VESA 75mm, 100mm, 200mm and 200mm x 200mm mounting hole patterns
- One-touch tilt allows tilt adjustment of +15/-5 degrees without the use of tools
- Desired tilt angle can be locked in place if needed
- Screen adapter brackets simply hook onto the wall plate for quick and easy installation
- Security screws lock down the screen for effective theft deterrence
- Includes hardware for installation to single wood stud, concrete, and cinder block
- UL tested to four times the stated weight load capacity

#### FEATURES

DEPTH 2.86" (7.26 cm)  
WIDTH 12" (30.48 cm)  
HEIGHT 10.25" (26.03 cm)

LOAD CAPACITY 115 lbs (52.16 kg)

PRODUCT WEIGHT 6.12 lbs (2.77 kg)

FINISH Scratch Resistant Fused Epoxy

AVAILABLE COLORS  
Black: ST635, ST635P  
Silver: ST635S, ST635S-P

ACCESSORIES  
Metal Stud Fastener Kit (ACC 215)  
Video Conferencing Shelf (ACC 309)  
Accessory Shelves (PM 600, PM 610)

PATENTED Patent Pending



Side View

#### Package Specifications

PACKAGE CONTENTS Tilting Wall Plate Assembly, Universal Brackets, Mounting Hardware

UNITS IN PACKAGE 1

PACKAGE SIZE 4.25" (L) x 14.25" (W) x 7" (H) (10.79 x 37.46 x 17.78 cm)

PACKAGE SHIP WEIGHT 6.75 lbs (3.06 kg)

PACKAGE UPC CODE  
ST635: 735029236603  
ST635P: 735029236597  
ST635-S: 735029236580  
ST635P-S: 735029236573

LIMITED 5-YR. WARRANTY

(800) 865-2112  
www.peerlessindustries.com

Peerless Industries, Inc.  
3215 W. North Avenue, Melrose Park, IL 60160  
(708) 865-8870 or (800) 865-2112 Fax: (708) 865-2941 www.peerlessindustries.com

© 2005 Peerless Industries, Inc. All rights reserved.  
SmartMount is a trademark and Peerless is a registered trademark of Peerless Industries, Inc.



LIT-0108